MINI Hi-Fi COMPONENT SYSTEM

SONY

HCD-H701 is the CD player and stereo deck receiver in FH-G70/ MHC-701/MHC-S300.

HCD-H701

CD SECTION	Model Name Using Similar Mechanism	HCD-H801
	CD Mechanism Type	CDM28-5BD19
	Base Unit Type	BU-5BD19
TAPE DECK SECTION	Model Name Using Similar Mechanism	HCD-H801
	Tape Transport Mechanism Type	TCM-220WR2

Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
"DOLBY" and the double-D symbol ◻◻ are trademarks of Dolby Laboratories Licensing Corporation.

MHC-690

• The MHC-690 is composed of the models below.
Service manuals are issued for each of the component models, so please refer to each of the manuals.

COMPONENTS MODEL

	MHC-690				
	AEP	G	IT	AED	EE
COMPACT DISC STEREO DECK RECEIVER	HCD-H690				
SPEAKER	SS-H690				

HCD-H690

Model HCD-H690 is almost same as HCD-H701.
As only the difference from HCD-H701 is described in this manual, please refer HCD-H701 service manual for the other section.

Page HCD-H701	HCD-H690 No.	Part No.	Description
64	1	4-971-955-21	PANEL, LOADING
	* 7	4-980-809-01	PANEL, BACK (AEP)
	* 7	4-980-809-11	PANEL, BACK (G)
	* 7	4-980-809-21	PANEL, BACK (IT)
	* 7	4-980-809-41	PANEL, BACK (EE)
65	51	X-4946-932-1	LID (B) ASSY, CASSETTE
	52	X-4946-931-1	LID (A) ASSY, CASSETTE
	53	4-971-956-21	BUTTON (EJ-A)
	58	4-971-957-21	BUTTON (EJ-B)
66	102	4-971-958-61	PANEL, FRONT (AEP, G, IT, EE)
	104	4-971-913-21	BUTTON (POWER)
	108	4-970-867-21	BRACKET (VOLUME)
	114	4-970-880-31	BUTTON (KARAOKE)
	117	X-4946-929-1	BUTTON (DBFB) ASSY
	118	X-4946-934-1	BUTTON (CD) ASSY
	119	X-4946-928-1	BUTTON (B) ASSY
	120	X-4946-939-1	BUTTON (TC-PLAY) ASSY
	121	X-4946-935-1	BUTTON (F/T) ASSY
	123	4-970-863-21	BUTTON (A)
	124	4-972-642-21	BUTTON (TC-STOP)